

# Frequent Walk-Through Inspection Checklist for USTs

<b>Date of Inspection</b>						
---------------------------	--	--	--	--	--	--

**Release Detection System:** Is the Incon on?  
Does it have paper? Is it in Alarm mode?

--	--	--	--	--	--	--

**Overfill Alarm:** Is the flapper valve located in the fill pipe?

--	--	--	--	--	--	--

**Certificate of Registration:** Do you have a current Certificate? Does it have the correct owner, address, and # of tanks?

--	--	--	--	--	--	--

**Fill and Monitoring Ports:** Inspect all fill/monitoring ports and other access points to make sure that the covers and caps are tightly sealed and locked.

--	--	--	--	--	--	--

**Dispenser Hoses, Nozzles, and Breakaways:** Inspect for loose fittings, deterioration, obvious signs of leakage, and improper functioning.

--	--	--	--	--	--	--

**Dispenser and Dispenser Sumps:** Open each dispenser and inspect all visible piping, fittings, and couplings for any signs of leakage. If any water or product is present, remove it and dispose of it properly. Remove any debris from the sump.